


CATRAHONE DIAMOND POWER Powered Knife Sharpener

Thank you for your purchase of the CATRAHONE, please take a few moments to read this leaflet for the safe usage and operating procedure

The CATRAHONE has 3 slots for sharpening,

- 1 Coarse grinding wheels nearest the main body, this is for forming the 34° angle on badly worn or damaged blades.
- 2 Fine grinding wheels in the middle slot, this is for everyday sharpening of most blades
- 3 The end slot does contain a honing rather than an abrasive wheel, this give a fine finish to the cutting edge and should be used the most often.



Sharpening a badly blunt or damaged blade.

- 1 Plug the unit into a standard socket there is no switch on the sharpener so the motor will start straight away
- 2 Gently lower the blade into slot 1 near the handle end
- 3 Slowly pull the blade back and forth until a new edge is formed. This could take between 5 and 30 strokes depending on how badly worn the blade is.
- 4 Move the blade to the middle slot (2) and repeat the sharpening; it should take only 4 or 5 strokes if the previous operation was completed correctly.
- 5 Move the blade to the end slot (3) and repeat the procedure in step 4.

Once the blade has been sharpened by the CATRAHONE the knife can be kept sharp by regular use of the honing wheels in slot 3 and occasional use of the fine wheels in the middle slot

Overuse of the grinding wheels will cause premature wear on the blade.

It is important not to press too hard, a medium size blade should sharpen under its own weight where as a small blade may need extra pressure and a large blade less.

Specification

Abrasive: Diamond
Sharpened Angle: 34°
Grinding Wheel Dia: 20mm
Motor: 24VDC with 110/240 Power Supply
Noise Level: <80 dBa (Whisper quiet)
Size: 200mm * 60mm * 80mm
Weight: 850g
Dust Collection: Magnetic
Use: For Domestic and very light commercial use, such as small shops and restaurants

Warranty

This product is guaranteed for 12 months from the date of purchase for all manufacturing defects, subject to fair wear and tear.

No user serviceable parts, opening the sharpener may invalidate the warranty.

All statutory rights are protected.

Care and Safety

Remove the cap in the base and clean the magnet every month

Do not immerse the sharpener in water

Do not Place in a Dishwasher

Clean the exterior with a damp cloth

Not for use by children

Do not Drop

Contact

CATRA
Henry Street
Sheffield
UK
S3 7EQ



Tel: +44 (0) 114 2769736

Email: sales@catra.org

Web: www.catra.org

Designed and Built in Sheffield